
Milaeger's

Setting up your incandescent lighted Christmas tree

- 1. Install the bottom section of the tree into the stand provided, making certain that it is seated firmly.
- 2. Remove the shrink wrap and allow the branches to fall into place.
- 3. Locate the stack of plugs (A) near the center pole and connect it to your own extension cord (B). Plug it into the wall.
- 4. Connect the pole from the middle section into the pole of the bottom section.
- 5. Remove the shrink wrap and allow the branches to fall into place.
- 6. Locate the stack of plugs in the center of the middle section **(C)**. Check to be sure the bottom of the stack is attached to a short extension cord **(D)**, provided with your tree.
- 7. Allow the extension cord to run down through the center of the bottom section. Connect this cord to your extension cord that already has stack (A) plugged into it. Use the other side.
- 8. Connect the pole from the top section to the middle section of the tree.
- 9. Remove the shrink wrap.
- 10. Locate the 2 or 3 plugs hanging from the top of the tree **(E)** and attach them to the top of the plug stack in the middle section **(C)**.
- 11. Your tree should now be fully lit.
- 12. If some lights do not come on, check to make sure that all of the plugs in the stacks are connected together.
- 13. Fluff the branches and tips to the desired fullness for your Christmas enjoyment.



OPTIONAL

Foot Pedal connects to **B**. Plug **A** and **D** into it.